

100

FIG. 1




FIG. 2

# Flow Loss Detection

200

The meter "learns" the typical flow pattern for weekends and weekdays






FIG. 4

# Pump Stations or Industrial Flows

Instead of lowering the % threshold, a moving boxcar average is applied to the flow data in the meter.

Erratic flow could cause false alarms





FIG. 5


500



2080E0-0562600T

600


FIG. 6



208050" 0562600F


700

FIG. 7



800

FIG. 8



2080E0"0562600T  
2080E0"0562600T



FIG. 9




FIG. 10

200802095626001

